



U.S. General Services Administration



Ambulance Technology and Standards Update Part I

James D. Green
National Institute for Occupational Safety and
Health (NIOSH)

2015 Federal Fleet Management Training
General Services Administration



GSA Motor Vehicle Management Value Proposition

2015 Federal Fleet Management Training



Right Vehicle



Right Price



Great Service

*and the required data needed to effectively and
efficiently manage a fleet*



Ambulance Design - Then





Ambulance Design - Now





Why do we seek opportunities for improvement?



Prior to crash equipment and gurney either mounted or stowed in cabinets



Post crash (rollover) equipment and gurney positions drastically changed



Background & Participants

Bringing the right expertise to address the problems to be solved:

Improving Occupant Safety



Overarching Goals of this Research

- Provide patient compartment occupants with the same level of crash protection as passenger vehicles
- Work with end users to ensure designs meet needs
- Near Term: Develop system specific test methods for publication to be referenced nationally or internationally
- Long Term: Incorporate changes into one or more bumper-to-bumper ambulance national standards

***** Most Importantly - Ensure all proposed test methods are based on actual test data *****



Industry Partners

- National Truck Equipment Association's Ambulance Manufacturer's Division
 - Represents 20 ambulance builders
 - Over 90% of US ambulances are manufactured by AMD members
- Patient Litter Manufacturers – 100% of the US market
 - Stryker Medical
 - Ferno Washington
- Seating Manufacturers – over 90% of all EMS seating
 - EVS Limited
 - Wise Seating
 - Serenity Safety Products



Automotive Testing Expertise Applied

- Testing performed by three private companies at five different crash test facilities from Wisconsin to Virginia
 - Center for Advanced Product Evaluation (CAPE)
 - MGA Research
 - Transportation Research Center
- National Highway Traffic Safety Administration's
 - Vehicle Research Test Center, East Liberty, Ohio
 - Office of Vehicle Crashworthiness Research, Washington, DC
- General Services Administration
- Federal Aviation Administration



Crash Standard Development

Vehicle Response Provides Foundation for Future Work



What Impact Load Should We Use?



≈ 30 mph – likely survivable




≈ 60 mph – likely not survivable

"Ride of your Life: What you Can't Afford Not to Know About Ambulance Safety", Levick, N. Presented at TSJC/RETAC EMS Symposium "Making A Difference" February 11, 2012, Alamosa, Colorado



Conducted 3 Frontal Impact Tests: 30 MPH Into Barrier





Conducted 4 Side Impact Tests at 30 MPH Using a 3,3300 lb. MDB





Test Load Criteria – Frontal & Side Impact

SAE International

SURFACE VEHICLE RECOMMENDED PRACTICE

Occupant Restraint and Equipment Mounting Integrity – Frontal Impact System-Level Ambulance Patient Compartment

SAE J2917 MAY2010

Issued 2010-05

Not applicable.

1. SCOPE

This SAE Recommended Practice defines the equipment mounting characteristics and equipment mounting testing for ambulances. The test fixtures are indicated.

2. REFERENCES

2.1 Applicable Publications

The following publications represent the latest issue of SAE publications.

2.1.1 SAE Publications

Available from SAE International (USA and Canada) or 770-440-2100

SAE J211-1

SAE J211-2

SAE Engineering Aid 2

Current, R.S., Moore, J.

SAE Technical Paper 2001-01-0001

2.2 Other Publications

Code of Federal Regulations, 49 CFR 571.212

Code of Federal Regulations, 49 CFR 571.212

Code of Federal Regulations, 49 CFR 571.212

SAE Technical Standards Board

SAE reviews each technical report for technical accuracy and for compliance with SAE standards. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of SAE International.

SAE WEB ADDRESS:

SAE J2917 Issued MAY2010

Page 3 of 4

FIGURE 1 - DYNAMIC SLED CORRIDOR

| Position | Time (sec) | Acceleration (g) | Position | Time (sec) | Acceleration (g) |
|----------|------------|------------------|----------|------------|------------------|
| A | 0.000 | -4.0 | I | 0.004 | 0.0 |
| B | 0.005 | -17.5 | J | 0.014 | -13.5 |
| C | 0.020 | -17.5 | K | 0.016 | -13.5 |
| D | 0.028 | -14.0 | L | 0.023 | -9.5 |
| E | 0.045 | -14.0 | M | 0.055 | -9.5 |
| F | 0.055 | -22.5 | N | 0.063 | -17.5 |
| G | 0.082 | -22.5 | O | 0.075 | -17.5 |
| H | 0.125 | 0.0 | P | 0.090 | 0.0 |

SAE J2917- Ambulance Patient Compartment Frontal HYGE Sled Pulse, May 2010

SAE International

SURFACE VEHICLE RECOMMENDED PRACTICE

Occupant Restraint and Equipment Mounting Integrity – Lateral Impact System-Level Ambulance Patient Compartment

SAE J2956 JUN2011

Issued 2011-06

Downloaded from SAE International by GSA, Thursday, October 23, 2014

SAE J2956 Issued JUN2011

Page 3 of 4

This standard was developed to meet the industry's need for ambulance. The standard was developed by SAE International and its member organizations.

1. SCOPE

This SAE Recommended Practice defines the equipment mounting characteristics and equipment mounting testing for ambulances. The test fixtures are indicated.

2. REFERENCES

2.1 Applicable Publications

The following publications represent the latest issue of SAE publications.

2.1.1 SAE Publications

Available from SAE International (USA and Canada) or 770-440-2100

SAE J211-1

SAE J211-2

SAE Engineering

SAE J2956 Issued JUN2011

Page 3 of 4


FIGURE 1 - DYNAMIC SLED CORRIDOR

| Position | Time (sec) | Acceleration (g) | Position | Time (sec) | Acceleration (g) |
|----------|------------|------------------|----------|------------|------------------|
| A | 0 | -6.0 | F | 0.005 | 0.0 |
| B | 0.009 | -26.0 | G | 0.016 | -19.0 |
| C | 0.036 | -26.0 | H | 0.029 | -19.0 |
| D | 0.045 | -10.0 | I | 0.035 | 0.0 |
| E | 0.055 | -10.0 | | | |

SAE J2956- Ambulance Patient Compartment Lateral HYGE Sled Pulse, June 2011



Standards Landscape Tomorrow





Seat and Worker Restraint: Test Methodology

SAE J3026 Published in August 2014

| | | |
|--|---|------------------------------|
| SAE International | SURFACE VEHICLE RECOMMENDED PRACTICE | |
| | SAE | J3026 PropDft XXX2013 |
| | Issued | Date (OrigDate) |
| | Revised | Proposed Draft (LastDate) |
| | Cancelled | Date (CancelledDate) |
| Superseding Jxxxx, Date SupersededBy | | |
| Ambulance Patient Compartment Seating Integrity and Occupant Restraint | | |

RATIONALE

This SAE Recommended Practice was developed by members of the SAE Truck Crashworthiness Committee in support of the ambulance industry's need to apply science to the design and testing of the occupant seating and occupant restraint systems for workers and civilians transported in the patient compartment of an ambulance. The Recommended Practice was validated collaboratively by industry and government partners through extensive testing funded by the National Institute for Occupational Safety and Health and the Department of Homeland Security. Input loading was generated using the vehicle specific crash pulses described in SAE J2917 and SAE J2956, respectively. An independent analysis of the testing methodology and resulting data was performed by government and private members of the automotive testing community that did not have a stake in this effort.

1. SCOPE

This SAE Recommended Practice describes the testing procedures required to evaluate the integrity of ground ambulance-based occupant seating and occupant restraint systems for workers and civilians transported in the patient compartment of an ambulance when exposed to a frontal or side impact. Its purpose is to provide seating and occupant restraint manufacturers, ambulance builders, and end-users with testing procedures and, where appropriate, acceptance criteria that, to a great extent ensures the occupant seating and occupant restraint systems meet the same performance criteria as is applied to a civilian vehicle's seating and occupant restraint system. Descriptions of the test set-up, test instrumentation, photographic/video coverage, test fixture, and performance metrics are included.

2. REFERENCES

The following publications form a part of this specification to the extent specified herein. Unless otherwise indicated, the latest issue of SAE publications shall apply.

2.1 Applicable Publications

Available from SAE International, 400 Commonwealth Drive, Warrendale, PA 15096-0001, Tel: 877-806-7323 (inside USA and Canada) or 724-776-4970 (outside USA), www.sae.org

SAE J211-1 Instrumentation for Impact Test—Part 1: Electronic Instrumentation

SAE J211-2 Instrumentation for Impact Test—Part 2: Photographic Instrumentation

SAE Engineering Aid 23 "Users' Manual for the 50th-Percentile Hybrid-III Test Dummy," June 1985
SAE J2917 Occupant Restraint and Equipment Mounting Integrity—Frontal Impact System-Level

Key Elements in this Recommended Practice

- Dynamic, crash testing is required
- Seat and restraint systems must protect occupants to same crash standard as automotive seating
- Loading to the crash test dummy must fall below automotive test limits




Frontal Impact, Forward and Rear Facing Seating





Mapping Occupant Excursion

SAE J3059 Submitted for Review and Approval

| | | |
|---|---|---------------------------------------|
|  | SURFACE VEHICLE RECOMMENDED PRACTICE | SAE J3059 PropDft Aug 28, 2014 |
| | | Issued Date (Orig Date) |

Ambulance Patient Compartment Seated Occupant Excursion Zone Evaluation

RATIONALE

This SAE Recommended Practice was developed by members of the SAE Truck Crashworthiness Committee in support of the ambulance industry's need to apply science to the design and testing of the occupant seating and occupant restraint systems for workers and civilians transported in the patient compartment of an ambulance. The Recommended Practice was validated collaboratively by industry and government partners through extensive testing funded by the National Institute for Occupational Safety and Health, the Department of Homeland Security and the Ambulance Manufacturers Division of the NTEA. Input loading was generated using the vehicle specific crash pulses described in SAE J2917 and SAE J2956, respectively. An independent analysis of the testing methodology and resulting data was performed by government and private members of the automotive testing community.

1. SCOPE

This SAE Recommended Practice describes the testing and reporting procedures that may be used to evaluate and document the excursion of a worker or civilian when transported in a seated and restrained position in the patient compartment of a ground ambulance when exposed to a frontal or side impact. Its purpose is to provide seating and occupant restraint manufacturers, ambulance builders, and end-users with testing procedures and documentation methods needed to identify potential head impact locations and/or head travel paths in crash loading events. This is a component level test. The seating system is tested in free space to measure maximum head travel paths. The purpose is not to develop stay out zones. Rather, the goal is to provide ambulance manufacturers with the data needed to design safer and functionally sound work stations for Emergency Medical Service workers so that workers are better able to safely perform patient care tasks in a moving ambulance. Descriptions of the test set-up, test instrumentation, photographic/video coverage, test fixture, and reporting requirements are included.



2. REFERENCES

The following publications form a part of this specification to the extent specified herein. Unless otherwise indicated, the latest issue of SAE publications shall apply.

2.1 Applicable Publications


Available from SAE International, 400 Commonwealth Drive, Warrendale, PA 15096-0001, Tel: 877-806-7323 (inside USA and Canada) or 724-776-4970 (outside USA), www.sae.org.

SAE J211-1 Instrumentation for Impact Test—Part 1: Electronic Instrumentation





Seating and Restraint Data Sheet





Patient Cot and Restraint: Test Methodology

SAE J3027 Published in July 2014

| | | | |
|--------------------------|---|--|---|
| SAE International | SURFACE VEHICLE RECOMMENDED PRACTICE | SAE J3027 PropDft XXX2013 | |
| | | Issued | Date (OrigDate) |
| | | Revised | Proposed Draft (LastDate) |
| | | Cancelled | Date (CancelledDate) |
| | | Superseding JxxxxDate SupersededBy | |
| | | Ambulance Litter Integrity, Retention, and Patient Restraint | |

RATIONALE

This SAE Recommended Practice was developed by members of the SAE Truck Crashworthiness Committee in support of the ambulance industry's need to apply science to the design and testing of the patient litter, its attaching hardware to the vehicle, and the restraint system for the patient. The Recommended Practice was validated collaboratively by industry and government partners through extensive testing funded by the National Institute for Occupational Safety and Health and the Department of Homeland Security. Input loading was generated using the vehicle specific crash pulses described in SAE J2917 and SAE J2956, respectively. An independent analysis of the testing methodology and resulting data was performed by government and private members of the automotive testing community that did not have a stake in this effort.

1. SCOPE

This SAE Recommended Practice describes the testing procedures required to evaluate the integrity of a ground ambulance-based patient litter, litter retention system, and patient restraint when exposed to a frontal or side impact. Its purpose is to provide litter manufacturers, ambulance builders, and end-users with testing procedures and, where appropriate, acceptance criteria that, to a great extent ensures the patient litter, litter retention system, and patient restraint meet the same performance criteria as is applied to a civilian vehicle's seating and occupant restraint system. Descriptions of the test set-up, test instrumentation, photographic/video coverage, test fixture, and performance metrics are included.

2. REFERENCES

The following publications form a part of this specification to the extent specified herein. Unless otherwise indicated, the latest issue of SAE publications shall apply.

2.1 Applicable Publications

Available from SAE International, 400 Commonwealth Drive, Warrendale, PA 15096-0001, Tel: 877-806-7323 (inside USA and Canada) or 724-776-4970 (outside USA), www.sae.org.

SAE J211-1 Instrumentation for Impact Test—Part 1: Electronic Instrumentation

SAE J211-2 Instrumentation for Impact Test—Part 2: Photographic Instrumentation

SAE Engineering Aid 23 "Users' Manual for the 50th-Percentile Hybrid-III Test Dummy," June 1985

Key Elements in Recommended Practice

- Dynamic, crash testing is required
- Cot, cot mounting and restraints structurally sound during simulated crash loading
- Occupant excursion reduced to less than 14 inches



Standard Litter – 30 mph Barrier Impact

**Pre-crash
event: standard
litter, restraint
and antler floor
fastener**



**Worker in
rear-facing
seat**

**Mid-crash
event: patient
excursion
exceeds 30
inches or 76 cm**




**Worker
impacted by
patient**



Rigid Litter With New Restraint Tested Using J2917




**Pre-crash event: rigid
litter, new restraint
applied directly to
shoulder**



**Mid-crash event: total
head excursion of 7.8
in / 20 cm**



30 MPH Sled Test – Production Litter (SAE J2917)



Production litter with new patient restraint and floor mount system

Production litter: Occupant excursion falls below maximum limit of 14 inches even when including excursion associated with litter frame deflection






Patient Litter & Restraint: Patient Excursion

(14 inch Maximum Excursion Limit – The Goal Line View)

Production litter, litter floor fixture, and occupant restraint – max excursion 11” This test meets the new standard

**** Manufacture not identified due to confidentiality agreement**





Ramp and Cart Roll Tests with Cots: 30 MPH




A new prototype litter and instrumented crash test dummy installed in each ambulance – one from Stryker and one from Ferno

Both litters and their floor fixtures remained structurally sound, with the patient securely restrained. Dummy parameters fell below NHTSA limits





Traditional Standard Litter or Cot Floor Fixture



This system was designed to attenuate only 2,200 lbs. of loading



Ambulance Design - Now



New Litter Floor Mount Systems Have robust, Positive Locking Mechanisms



Power-LOAD™

Cot Fastener System





Equipment Mounting: Test Methodology

SAE J3043 Published in July 2014

| | | |
|---|---|--|
|  | SURFACE VEHICLE RECOMMENDED PRACTICE | SAE J3043 Prop ^{Dft} August 13 th , 2013 |
| | | Issued Date (Orig Date) Revised Proposed Draft (Last Date) Cancelled Date(Cancelled Date) Superseding Jxxxx Date Superseded By |
| Ambulance Equipment Mount Device or Systems | | |
| <p align="center">RATIONALE</p> <p>This SAE Recommended Practice was developed by members of the SAE Truck Crashworthiness Committee in support of the ambulance industry's need to apply science to the design and testing of the equipment mount devices or systems used in the ambulance patient compartment. The Recommended Practice was validated collaboratively by industry and government partners through extensive testing funded by the National Institute for Occupational Safety and Health and the Department of Homeland Security. Input loading for the dynamic testing was generated using the vehicle specific crash pulses described in SAE J2917 and SAE J2956, respectively. An independent analysis of the testing methodology and resulting data was performed by government and private members of the automotive testing community that did not have a stake in this effort.</p> <p>1. SCOPE</p> <p>This SAE Recommended Practice describes the dynamic and static testing procedures required to evaluate the integrity of an equipment mount device or system when exposed to a frontal or side impact (i.e. a crash impact). Its purpose is to provide equipment manufacturers, ambulance builders, and end-users with testing procedures and, where appropriate, acceptance criteria that, to a great extent, ensure equipment mount devices or systems meet the same performance criteria across the industry. Prospective equipment mount manufacturers or vendors have the option of performing either dynamic testing or static testing. Descriptions of the test set-up, test instrumentation, photographic/video coverage, test fixture, and performance metrics are included.</p> <p>2. REFERENCES</p> <p>The following publications form a part of this specification to the extent specified herein. Unless otherwise indicated, the latest issue of SAE publications shall apply.</p> <p>2.1 Applicable Publications</p> <p>Available from SAE International, 400 Commonwealth Drive, Warrendale, PA 15096-0001, Tel: 877-806-7323 (inside USA and Canada) or 724-776-4970 (outside USA). www.sae.org</p> <p>SAE J211-1 Instrumentation for Impact Test—Part 1: Electronic Instrumentation</p> | | |

Key Elements in Recommended Practice


- Dynamic testing based on published pulses is an option
- Static test in lieu of dynamic test is also an option
- Innovative conversion from dynamic to static test loading offered



Equipment Mounting: Dynamic Test Option

Dynamic Test

- Simulates crash loading directly
- Utilizes front and side crash pulses from SAE J2917 and SAE J2956
- Equipment must be retained in mount throughout the test





Equipment Mounting: Static Test Option

Static Test

- Is a simple, one axis pull test
- Estimated loading increased by 50%
- Should be performed in multiple axis; one pull at a time




Static Load = Peak G x Weight x 1.5 amp factor
Example: (10 lb. O2 Cylinder. Tested for 22.5 G frontal impact requires a pull test of: $10 \times 22.5 \times 1.5 = 340$ lbs.)



Cabinet Closure & Retention: Test Methodology

SAE J3058 Will be submitted for publication summer 2015




Key Elements in Recommended Practice

- Dynamic testing based on published crash pulses
- Cabinet is to have a weight rating – rated by manufacturer
- Cabinet must stay closed to retain contents
- Cabinet must remain attached to simulated wall surface




Cabinet Closure & Retention: Test Methodology



Side
Section View

Front View

Multiple Shelf
Cabinet




Side
Section View

Single
Cabinet



Modular Body Structural Integrity: Test Methodology

SAE J3058 Will be submitted for publication summer 2015

| | | | | | | | | | | | | | | |
|---|---|-------|--------------------|--------|---------|---------|---------|------------|---------|------------|---------|-----------|---------|-------------|
|  | SURFACE VEHICLE RECOMMENDED PRACTICE | J30XX | PropDft JAN2013 | | | | | | | | | | | |
| | <table><tr><td>Issued</td><td>xxxx-xx</td></tr><tr><td>Revised</td><td>xxxx-xx</td></tr><tr><td>Reaffirmed</td><td>xxxx-xx</td></tr><tr><td>Superseded</td><td>xxxx-xx</td></tr><tr><td>Cancelled</td><td>xxxx-xx</td></tr><tr><td>Superseding</td><td>xxxxxx, Date</td></tr></table> | | | Issued | xxxx-xx | Revised | xxxx-xx | Reaffirmed | xxxx-xx | Superseded | xxxx-xx | Cancelled | xxxx-xx | Superseding |
| Issued | xxxx-xx | | | | | | | | | | | | | |
| Revised | xxxx-xx | | | | | | | | | | | | | |
| Reaffirmed | xxxx-xx | | | | | | | | | | | | | |
| Superseded | xxxx-xx | | | | | | | | | | | | | |
| Cancelled | xxxx-xx | | | | | | | | | | | | | |
| Superseding | xxxxxx, Date | | | | | | | | | | | | | |
| Ambulance Modular Body Evaluation-Quasi-Static loading For Type I and Type III Modular Ambulance Bodies | | | | | | | | | | | | | | |

RATIONALE

This SAE Recommended Practice was developed by members of the SAE Truck Crashworthiness Committee in support of the ambulance industry's need to apply science to the design and testing of the ambulance modular body for Type I and Type III bodies. The Recommended Practice was validated collaboratively by industry and government partners through extensive testing funded and managed by the National Institute for Occupational Safety and Health, the Department of Homeland Security and the Ambulance Manufacturers Division of the NTEA. Input loading for the dynamic testing was generated using the test methodology described in ECE R66. An independent analysis of the testing methodology and resulting data was performed by government and private members of the automotive testing community.

1. SCOPE

This SAE Recommended Practice describes the test procedures to be used to evaluate the strength of a modular ambulance body roof and side wall. This test methodology includes a dynamic and two quasi-static tests performed in combination. Its purpose is to establish repeatable test methodology which will be adopted as standardized test procedures for Type I, Type I-AD, Type III or Type III-AD bodies. This Recommended Practice provides ambulance builders and end-users with testing procedures and, where appropriate, acceptance criteria that, to a great extent, ensure the ambulance structure meets the same performance criteria across the industry. Descriptions of the test set-up, test instrumentation, photographic/video coverage, and the test fixtures are included.

2. REFERENCES

The following publications form a part of this specification to the extent specified herein. Unless otherwise indicated, the latest issue of SAE publications shall apply.

2.1 Applicable Publications

Available from SAE International, 400 Commonwealth Drive, Warrendale, PA 15096-0001, Tel: 877-806-7323 (inside USA and Canada) or 724-776-4970 (outside USA), www.sae.org.

SAE J211-1 Instrumentation for Impact Test—Part 1: Electronic Instrumentation

SAE J211-2 Instrumentation for Impact Test—Part 2: Photographic Instrumentation

SAE Technical Standards Board Rules provide that: "This report is published by SAE to advance the state of technical and engineering sciences. The use of this report is authorized by its published content and is not to be used for advertising, promotional, or sales promotion purposes without express written permission of SAE. This report is not to be used in any way that may constitute an infringement of the patent rights of any individual or organization." SAE reserves the right to modify this report at any time without notice, and is not responsible for the consequences of any misuse of this report.

Key Elements in 3 Phase Recommended Practice

- Phase 1 is a dynamic test where patient compartment is impacted by large mass
- Phases 2 & 3 are both quasi-static tests evaluate roof and side wall strength
- Doors must open after each test with a minimal 66 lb. force applied



Roll Test Provides Impact Loading on Roof Edge



Utilized an Accepted Roll Test, ECE R66 to Collect Impact Load Data

Impacted Surface Measures Loads Using Force Plates – Much Like a Large Scale





Phase I: Dynamic Impact Simulates Roll Impact

28,000 lb. force derived from actual ambulance roll test





Phases 2 and 3: Quasi-Static Load on Roof and Side



Applied Load Equals 2.5 times GVWR first on roof then vehicle rolled on side and load applied again all using the same previously impacted modular body






Designing Safer Head Impact Regions



Ram and Instrumented Head Allow Engineers to Test Surfaces and Surface Treatments to Reduce Head Injury





Ongoing Research to Improve EMS Worker Safety

- EMS Worker Anthropometry Study – Assessing body sizes and shapes (640 human subjects to be measured – 480 complete)
- Development of a prototype ambulance based on this work plus companion research at NIST and DHS addressing patient compartment layout
- Production of an informational DVD to be provided to all EMS services nationwide



What can you do to encourage worker safety?

- Adopt the new safety test methods and standards as they are published
- Make it a priority to replace the patient cot/litter with each new ambulance purchase
- Strongly encourage the use of safety belts in the patient compartment in new and in older vehicles
- Strongly encourage employees to use shoulder restraints on the patient
- Stow or lock down medical equipment & supplies



Contact Information

Jim Green

NIOSH

304-285-5857

jgreen@cdc.gov

Disclaimer: The findings and conclusions in this presentation are those of the author and do not necessarily represent the views of the National Institute for Occupational Safety and Health. Mention of any company or product does not constitute endorsement by the National Institute for Occupational Safety and Health (NIOSH).



GSA Motor Vehicle Management Resources

- [GSA Fleet Drive-thru and Training](#)
- [Consolidate Your Vehicles With GSA Fleet](#)
- [Short Term Rental Program](#)
- [Dispatch Reservation Module](#)
- [Federal Fleet Management System \(FedFMS\)](#)
- [Car Sharing](#)
- [Alternative Fuel Vehicle Guide](#)
- [WEX Station Locator](#) / [DOE Station Locator](#)
- [2015 FFMT Presentations](#)